

## BATERIE PATONA PRO TOSHIBA 4400MAH



Cena celkem:	<b>979 Kč</b> <b>(bez DPH: 809 Kč)</b>
Běžná cena:	<b>1 077 Kč</b>
Ušetříte:	<b>98 Kč</b>
Kód zboží:	PORB0276
Part No.:	PT2307
Záruka:	24 měsíců/6 měs. akku
Stav:	Nové zboží

## Popis

### PATONA baterie pro Toshiba 4400 mAh

Kompatibilní baterie pro notebooky Toshiba. Baterie se vyznačují vysokou kvalitou, mají integrovanou ochranu proti přetížení a přebití.

### ZÁKLADNÍ SPECIFIKACE

**Kapacita:** 6600 mAh

**Technologie baterie:** Li-iontová

**Nahrazuje baterie:** PA3634U-1BAS, PA3635U-1BAM, PA3635U-1BRM, PA3638U-1BAP, PA3816U-1BAS, PA3816U-1BRS, PA3818U-1BRS, PA3634U-1BRS, PABAS117, PABAS178, PABAS227, PABAS228, PABAS229, TS-M305, PA3817U-1BRS

### Pro notebooky:

Toshiba Dynabook CX/45, Toshiba Dynabook CX/47, Toshiba Dynabook CX/48, Toshiba Dynabook MX/33, Toshiba Dynabook MX/34, Toshiba Dynabook MX/43, Toshiba Dynabook Qosmio T550, Toshiba Dynabook Qosmio T560, Toshiba Dynabook SS M52, Toshiba Dynabook T350, Toshiba Dynabook T551

Toshiba Equium U400

Toshiba Portege M800, Toshiba Portege M900

Toshiba Satellite A655, Toshiba Satellite A660, Toshiba Satellite A665, Toshiba Satellite C640, Toshiba Satellite C650, Toshiba Satellite C660, Toshiba Satellite L310, Toshiba Satellite L311, Toshiba Satellite L312, Toshiba Satellite L315, Toshiba Satellite L317, Toshiba Satellite L322, Toshiba Satellite L323, Toshiba Satellite L510, Toshiba Satellite L515, Toshiba Satellite L515, Toshiba Satellite L600, Toshiba Satellite L630, Toshiba Satellite L635, Toshiba Satellite L640, Toshiba Satellite L645, Toshiba Satellite L650, Toshiba Satellite L655, Toshiba Satellite L670

Toshiba Satellite M300, Toshiba Satellite M301, Toshiba Satellite M302, Toshiba Satellite M305, Toshiba Satellite M306, Toshiba Satellite M307, Toshiba Satellite M308, Toshiba Satellite M310, Toshiba Satellite M311, Toshiba Satellite M319, Toshiba Satellite M320, Toshiba Satellite M321, Toshiba Satellite M323, Toshiba Satellite M325, Toshiba Satellite M326, Toshiba Satellite M327, Toshiba Satellite M328, Toshiba Satellite M330, Toshiba Satellite M331, Toshiba Satellite M332, Toshiba Satellite M333, Toshiba Satellite M336, Toshiba Satellite M338, Toshiba Satellite M339, Toshiba Satellite M500, Toshiba Satellite M505, Toshiba Satellite M600, Toshiba Satellite M640, Toshiba Satellite M645

Toshiba Satellite P740, Toshiba Satellite P745, Toshiba Satellite P745, Toshiba Satellite P750, Toshiba Satellite P755, Toshiba Satellite P770, Toshiba Satellite P775, Toshiba Satellite T110, Toshiba Satellite T115, Toshiba Satellite T130, Toshiba Satellite T135, Toshiba Satellite U400, Toshiba Satellite U405, Toshiba Satellite U500, Toshiba Satellite U505

Toshiba Satellite Pro 3000, Toshiba Satellite Pro C650, Toshiba Satellite Pro C660, Toshiba Satellite Pro L510, Toshiba Satellite Pro L600, Toshiba Satellite Pro L630, Toshiba Satellite Pro L640, Toshiba Satellite Pro L650, Toshiba Satellite Pro L670, Toshiba Satellite Pro M300, Toshiba Satellite Pro PS300, Toshiba Satellite Pro T110, Toshiba Satellite Pro T130, Toshiba

Satellite Pro U400, Toshiba Satellite Pro U500